


DIAGRAM OF MON/D35-18M/CE



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
101	1133P-1444701-1	HANDLE GRIP	418	11380-1424701-1	GASKET			
102	11233-1444701-1	HANDLE UNIT A	419	113CE-1424701-1	ANVIL HOOL			
103	2040302-23010-0	E - RING	420	2040101-02060-2	HEX.SOC.HD.BOLT			
104	11324-1444701-1	FIXED PIN	421	2040403-07360-0	PIN			
105	2040403-09080-0	PIN	422	11324-1444702-1	FIXED PIN			
106	11328-1440001-1	PULL SPRING	423	1137F-1444701-1	LINK-BLOCK			
107	1131G-1421101-1	FIXED RING	424	11351-1424701-1	DRIVER GUIDE COVER			
108	11326-1440002-1	BASE	425	2040103-02030-2	COUNTER SUNK SCREW			
109	2040104-03040-2	HEX.SOC.HD.SCREW	426	11387-1420001-1	DRIVER			
301	2040100-02080-0	BOLT ASSY	427	2040101-01040-2	HEX.SOC.HD.BOLT			
302	1137A-1441302-1	COVER-SAFETY B	428	2040201-01040-0	FLAT WASHER			
303	2040104-04020-0	HEX.SOC.HD.SCREW	429	113CG-1424701-1	PENETRATION ECCENTRIC			
304	2040500-04020-0	LOCK NUT	430	113CF-1424701-1	BUSHING			
305	1137A-1441301-1	COVER-SAFETY	431	1133W-1424701-1	PUSHER BEARING			
306	1137K-1444702-1	HANDLE B	432	1134X-1424701-1	SPRING			
307	2040101-02060-0	HEX.SOC.HD.BOLT	433	113CC-1420702-1	PENETRATION CONTROL KNOB			
401	113CH-1421303-1	REAR COVER	434	1132C-1421303-1	FRONT BEARING PLATE			
402	11303-1424701-1	DRIVER GUIDE	435	2040100-02070-0	BOLT ASSY			
403	11386-1424701-1	ROLLING ELEMENT	436	2040401-05070-0	SPIRAL PINS			
404	11372-1420001-1	SPRING						
405	2040103-02050-0	COUNTER SUNK SCREW						
406	11273-1424701-1	MAGAZINE UNIT						
407	2040103-02060-2	COUNTER SUNK SCREW						
408	1133E-1424701-1	PIN E/E.E.XT.HANDLE						
409	113CB-1444701-1	LINK A						
410	1133G-1424701-1	PUSHER PIN						
411	11363-1424701-1	PUSHER						
412	2040107-02111-0	TAP BOLT						
413	11390-1424701-1	PROTECTING HOOD COVER						
414	113CD-1420001-1	ANVIL HOLDER						
415	2040403-07060-0	PIN						
416	2040403-06040-0	PIN						
417	113CB-1424701-1	LINK						